

## Instruction Manual for Cash Boxes for POS Machines

### I. How to use

1. Remove the cash box from the cardboard box, then remove the foam and PE bag. Remove the key from the RJ11 cable and insert it into the keyhole, then rotate it counterclockwise.


Open the drawer 90 degrees, check its flexibility, and then move on to the next step.

2. Adjust the table to a level position and place the drawer on top.
3. Connect the RJ11 cable on the cash drawer to the computer or printer.

### II. Lock Operation and Functions

The Majie series drawers have 3-position locks, as follows:

- a. Control Mode: The image on the right shows the control mode, which can be accessed via computer or printer.
- b. Locking mode: Insert the key and rotate it 90 degrees clockwise to enter locking mode.
- c. Manual method: Insert the key, rotate counterclockwise 50 degrees, and open the drawer.



## Instruction Manual for Cash Boxes for POS Machines

### I. How to use

1. Remove the cash box from the cardboard box, then remove the foam and PE bag. Remove the key from the RJ11 cable and insert it into the keyhole, then rotate it counterclockwise.

Open the drawer 90 degrees, check its flexibility, and then move on to the next step.

2. Adjust the table to a level position and place the drawer on top.
3. Connect the RJ11 cable on the cash drawer to the computer or printer.

### II. Lock Operation and Functions

The Majie series drawers have 3-position locks, as follows:

- a. Control Mode: The image on the right shows the control mode, which can be accessed via computer or printer.
- b. Locking mode: Insert the key and rotate it 90 degrees clockwise to enter locking mode.
- c. Manual method: Insert the key, rotate counterclockwise 50 degrees, and open the drawer.

